



Cisco® 675 and 678 Modem

How to Configure the Modem RFC 1483 (Bridge) Configuration

1. You must have access to the modem “enable mode” to setup the modem.
2. Use these setup commands to configure the modem.

```
cbos> enable <Enter>
Password: <Enter>
cbos# set nvram erase <Enter>
cbos# write <Enter>
cbos# reboot <Enter>
      Password: <Enter> (unless you've set an exec password)
cbos> enable <Enter>
      Password: <Enter> (will bring up cbos# unless you've set an enable
password)
cbos# set bridging rfc1483 enable <Enter>
cbos# set bridging management enable <Enter> (this is not required but it
allows web management)
cbos# set int wan0-0 disable <Enter>
cbos# set int wan0-0 vpi 0 vci 32 <Enter>
              (vpi - 1 for cap and 0 for DMT)
              (vci - 1 for cap and 32 for DMT or 35 for AOL)
cbos# set int wan0-0 enable <Enter>
cbos# write <Enter>
cbos# reboot <Enter>
```